Product information- SWAP series



Want an easy way to save energy and automated control of motor, light, AC, heaters etc? Check out our SWAP series of product ! Learn more from page 6 to 53



Contents



- 1. SWAP product codes 5
- 2. Product technical specification 6
- 3. Product with 2 Module/1 Gang-Surface mount box installation 7
- 4. Product & Connection Details- "Auto OFF Timer" SWAP01E for Mono-block, Jet & Compressor Jet 8
- 5. Product & Connection details of SWAP01E Auto OFF Timer for Geysers/Water heaters 9
- 6. Product & Connection details of SWAP01E Auto OFF Timer with Green push button Starter 10
- 7. Product & Connection details SWAP01E with starter for single phase submersible pumps 11,12
- 8. Product & Connection details of SWAP01E for DOL/Star-Delta Starter -13
- 9. Connection details of SWAP01E with DOL/Star-Delta Starter -14
- 10. Product & Connection details of SWAP02E Auto OFF Timer for Street, Compound & Signboard lightings -15
- 11. Product & connection details of SWAP03C "Cyclic Timer" for Street, Compound & Signboard lightings 16
- 12. Product & connection details of SWAP03C-1 Cyclic Timer for Mono-block & Jet Pumps 17
- 13. Product & connection details of SWAP03C-2 Cyclic Timer for Mono-block & Jet Pumps 18
- 14. Product & connection details of SWAP03C-3 Cyclic Timer for Mono-block & Jet Pumps 19
- 15. Product & Sensor integration details of SWAP03C-1,2,3-OF(Over flow controller) for Mono-block & Jet Pumps 20



Contents



- 16. Product & Sensor integration details of SWAP03C-OF-MFS ("Overhead tank water level controller") for Mono-block & Jet Pumps -21
- 17. Product & Connection details of SWAP03AC "Cyclic Timer for Air Conditioner(AC)" 22
- 18. Product & Connection details of SWAP03-ACF-SA Cyclic Timer for Air Conditioner & Ceiling Fan control with add on Smoke detector & Alarm -23
- 19. Product & Connection details of SWAP04-OL (Overhead tank "water level controller") for Mono-block & Jet Pumps 24
- 20. Product & Sensor integration details of SWAP04-OL (Overhead tank water level controller) for Mono-block & Jet Pumps -25
- 21. Connection details of SWAP04-OLF (Overhead tank water level controller with "dry run protection") for Mono-block & Jet Pumps -26
- 22. Product & Sensor integration details of SWAP04-OLF (Overhead tank water level controller with dry run protection) for Mono-block & Jet Pumps -27
- 23. Connection details of SWAP04-C-OL(Overhead tank water level controller with Auto start capacitor) for Single Phase Submersible motor -28,29
- 24. Product & Sensor integration details of SWAP04-C-OL (Overhead tank water level controller with Auto start capacitor) for Submersible motor 30
- 25. Connection details of SWAP04-C-OLF(Overhead tank water level controller with dry run protection and Auto start capacitor option) for Single Phase Submersible Motor – 31,32
- 26. Product & Sensor integration details of SWAP04-C-OLF -33
- 27. Connection details of SWAP04-SOL ("Sump and overhead tank water level controller") for Mono-block & Jet Pumps 34
- 28. Product & Sensor integration details of SWAP04-SOL (Sump and overhead tank water level controller) for Mono-block & Jet Pumps -35
- 29. Connection details of SWAP04-C-SOL(Water level control for both sump and Overhead tank with Auto start capacitor option) for single phase Submersible motor – 36,37
- 30. Product & Sensor integration details of SWAP04-C-SOL(Water level controller) 38



Contents

- 31. Connection details of SWAP04-C-SOFL(Automatic Detection of Corporation water flow into the Sump with water level control for both V Sump and Overhead tank) for single phase Submersible motor – 39,40
- 32. Product & Sensor integration details of SWAP04-C-SOFL 41
- 33. Connection details of SWAP04-SMFL(Auto detection of Corporation water into the sump with sump level & flow control) for water pumps 42
- 34. Product & Sensor integration details of SWAP04-SMFL (Water Flow detector and level controller) 43
- 35. Product & Connection details of SWAP04-OF(Over flow controller) for Mono-block & Jet Pumps 44,45
- 36. Product & Connection details of SWAP04-OL-MFS (Overhead tank water level controller) for Mono-block & Jet Pumps 46
- 37. Product & Sensor integration details of SWAP04-OL-MFS (Overhead tank water level controller) for Mono-block & Jet Pumps 47
- 38. Product & Connection details of SWAP05E-BC "Battery charger Timer" for E-Vehicle battery chargers 48,49
- 39. How to set the time in "programmable auto-off timers" SWAP07E/SWAP07CD -50
- 40. Product & Connection Details- Programmable Auto OFF Timer-SWAP07E for Mono-block, Jet & Compressor Jet 51
- 41. Product & Connection details of SWAP07ECD "Count down Auto OFF Timer" for Geysers/Water heaters 52
- 42. How to set the cyclic time in "programmable cyclic timers" (On & Off time) 53
- 43. Product & connection details of "Cyclic Timer in minutes setting"-SWAP07ECY for Street, Compound & Signboard lightings 54
- 44. Product & connection details of "Cyclic Timer in hours setting" -SWAP07ECYH for Street, Compound & Signboard lightings -55



Auto-OFF Timers	Product codes 1. SWAP01 2. SWAP01E 3. SWAP02 4. SWAP02E	
Cyclic Timers	Product codes 1. SWAP03C 2. SWAP03AC 3. SWAP03ACF 4. SWAP03ACF-SA	
·		
Automatic level & flow controllers Product codes 1. SWAP04-OL-? 2. SWAP04-OLF 3. SWAP04-C-OL 4. SWAP04-C-OLF 5. SWAP04-SOL 6. SWAP04-C-SOL		
	7. SWAP04-C-SOFL 8. SWAP04-SMFL 9. SWAP04-OF	
Auto Off timers for e-vehicle battery chargers Product codes 1. SWAP05BC		
Auto Off timers (time opt	tions in seconds) Product codes 1. SWAP06	
Programmable (Auto-off	/cyclic timers/counters) Product codes 1. SWAP07E 2. SWAP07CD 3. SWAP07ECY 4. SWAP07ECYH	
	SWAP To Save water and power	




S



Description	Specification
Rated Load terminal Voltage	250VAC,50HZ / 30V DC
Rated control terminal Voltage	85-305V AC, 50/60Hz / 70-430V DC
Ratted current / Load	(16AX/2HP/3kW(Heating element)@AC / 20A@DC
Number of output / load channels	1 or 2 channels with load ratting(1@16AX, 2@8AX)
Mounting method	Flush/ Surface
Suitable box	2 Module Box / 1 Gang (From 25 mm Depth)
Conforms to standard	IS/IEC 60669-2
Color	White
Warranty	1 Year
Product weight	135 Grams
Product Dimensions	87x87x38mm
Product packaging box dimensions	100x100x70 mm

Product with 2 Module/1 Gang-Surface mount box installation





Step 1


Fix the 2 module box on wall & finish the wiring with SWAP terminals(Refer upcoming slides)

Step 2


Remove the front cover from the product using the slots provided and fix the product onto the 2 module box, using screws.

Step 3

Fit the removed front cover plate, back onto the product.



Product & Connection details of SWAP01E Auto OFF Timer for Geysers/Water heaters




E-mail address: info@eviqds.com

Contact Mobile: +91 9629900110,+91-9443410073


H)

Product & Connection details of SWAP01E Auto OFF Timer with Green push button Starter



E-mail address: info@eviqds.com

Product & Connection details - SWAP01E with starter for single phase submersible pumps




E-mail address: info@eviqds.com

Connection details - SWAP01E with single phase Submersible starter



Typical Starter appearance




While making any wiring connection first disconnect the power.




Step 1

First, remove wire from any one terminal of the red push button, and then connect that same wire to the L2 of the Auto-OFF Timer as shown in the image below.




Step 2 Take a new wire and connect one end to the red-Colored push button terminals and the other end to the L1 of the SWAP, as shown in the image below.





Now, without removing the existing L&N wire of the Starter panel, loop the L&N terminal of the Auto OFF Timer to the Starter panel.




Contact Mobile: +91 9629900110,+91-9443410073

E-mail address: info@evigds.com








E-mail address: info@eviqds.com


Connection details of SWAP01E with DOL/Star-Delta Starter






E-mail address: info@eviqds.com

Product & Connection details of SWAP02E Auto OFF Timer for Street, Compound & Signboard lightings



E-mail address: info@eviqds.com

Product & connection details of SWAP03C Cyclic Timer for Street, Compound & Signboard lightings



E-mail address: info@eviqds.com

Product & connection details of SWAP03C-1 Cyclic Timer for Mono-block & Design solutions

L1 & L21.52.5L & N1/1.5After installation, switch ON the main MCB,
then select the desired cycle on the SWAP
Auto Cyclic Timer. To select other time option

1-2 hp

(mm²)

Auto Cyclic Timer. To select other time option while the current cycle is running, press the red button and select the time of your choice.

Recommended wire cross section


0.25 - 1 hp

 (mm^2)

Motor loads

Connection

Terminals



E-mail address: info@eviqds.com

Product & connection details of SWAP03C-2 Cyclic Timer for Mono-block & A EVIO **Jet Pumps** 88 MADE IN INDIA IS / IEC 60669-2 F1-F2 10-415VAC 05-110VDC 16AX-2HP-3kW-250V-50Hz Cycle L1 L2 E1 E2 A1 A2 F1 F2 ON Hrs 0:15 0:15 0:20 0:20 0:25 0:25 0:30 0:30 2 1 2 1 2 1 2 Do not change polarity Swap **Motor loads** L2 L1 LOAD IN N **Recommended wire cross section** While making wiring connection first Connection 0.25 - 1 hp 1-2 hp **SWAP** disconnect the power. **Terminals** (mm^2) (mm²)**Cyclic** Line/ Phase **Timers** Inverter Phase/line L1 & L2 1.5 2.5 Neutral Recommended L & N

L

controller.

Contact us for overflow tank

After installation, switch ON the main MCB, then select the desired cycle on the SWAP Auto Cyclic Timer. To select other time option while the current cycle is running, press the red button and select the time of your choice.


1/1.5

N Supply Has feature for Autoexecution of same cycle in case of power Interruption.

Earth

Main


E-mail address: info@eviqds.com



E-mail address: info@eviqds.com


Contact Mobile: +91 9629900110,+91-9443410073

Product & Sensor integration details of SWAP03C-1,2,3-OF(Over flow controller) for Mono-block & Jet Pumps




E-mail address: info@eviqds.com

Product & Sensor integration details of SWAP03C-OF-MFS (Overhead tank water level controller) for Mono-block & Jet Pumps




Product & Connection details of SWAP03AC Cyclic Timer for Air Conditioner(AC)



E-mail address: info@evigds.com

Product & Connection details of **SWAP03-ACF-SA Cyclic Timer** for Air Conditioner & Ceiling Fan control with add on Smoke detector & Alarm.




E-mail address: info@eviqds.com

Contact Mobile: +91 9629900110,+91-9443410073

EV


Product & Connection details of SWAP04-OL (Overhead tank water level controller) for Mono-block & Jet Pumps



E-mail address: info@evigds.com


Product & Sensor integration details of SWAP04-OL (Overhead tank water level controller) for Mono-block & Jet Pumps





E-mail address: info@eviqds.com


Connection details of SWAP04-OLF (Overhead tank water level controller with dry run protection) for Mono-block & Jet Pumps



E-mail address: info@eviqds.com


Contact Mobile: +91 9629900110,+91-9443410073

EVIO



Connection details of SWAP04-C-OL(Overhead tank water level controller with Auto start capacitor) for Single Phase Submersible motor






E-mail address: info@eviqds.com

Connection details of SWAP04-C-OL with single phase Submersible starter

Step 3



Starter default appearance




While making any wiring connection first disconnect the power.




Step 1

First, remove the wire from any one terminal of the red push button, and then connect that same wire to the C-IN of the Auto-OFF Timer as shown in the image below.




Step 2 Take a new wire and connect one end to the red-Colored push button terminals and the other end to the C-out of the SWAP, as shown in the image below.







Now ,connect L1 and L2 across the starting capacitor, as shown in the image below. Then without removing the existing L&N wire of the Starter panel, loop the L&N terminal of the Auto OFF Timer to the Starter Panel.




Contact Mobile: +91 9629900110,+91-9443410073

E-mail address: info@eviqds.com

Product & Sensor integration details of SWAP04-C-OL(Overhead tank water level controller with Auto start capacitor) for Submersible motor






- 2. Automatic start capacitor option enabled for 3 seconds.
- 3. Two in one product (Automatic water level controller + Auto OFF timer).

4. Automatic off timer with feature for Auto-execution of the remaining time in case of power interruption.

Automatically switches ON the motor when the overhead tank water level is low. And switches OFF the motor when the water level becomes high. Auto-off timer can be used for the temporary filling up of water in the overhead tank (e.g. During scheduled powercut).

E-mail address: info@eviqds.com

Connection details of SWAP04-C-OLF(Overhead tank water level controller with dry run protection and Auto start capacitor option) for Single Phase Submersible Motor



E-mail address: info@eviqds.com


Contact Mobile: +91 9629900110,+91-9443410073

EVI

Connection details of SWAP04-C-OLF for single phase Submersible starter



Typical Starter appearance



While making any wiring connection first disconnect the power.




Step 1

First, remove the wire from any one terminal of the red push button, and then connect that same wire to the C-IN of the Auto-OFF Timer as shown in the image below.




Take a new wire and connect one end to the red-Step 2 Colored push button terminals and the other end to the C-out of the SWAP, as shown in the image below.





Step 3

Now connect L1 and L2 across the starting capacitor, as shown in the image below. Then without removing the existing L&N wire of the Starter panel, loop the L&N terminal of the Auto OFF Timer to the Starter Panel.



Contact Mobile: +91 9629900110.+91-9443410073

E-mail address: info@evigds.com


Product & Sensor integration details of SWAP04-C-OLF



Flow sensor/ Dry run protection

¼ (ft)

Outlet pipe



Product features

- 1. Automatic water level control for overhead tank.
- 2. Automatic start capacitor option enabled for 3 seconds.
- 3. Dry Run Protection for motor.
- 4. Automatic off timer Automatic off timer with Autoexecution of the remaining time in case of power interruption.

Product function

Overflow pipe

A/2

1/4 (ft)

Automatically switches ON the motor when the overhead tank water level is low and checks if the motor is running out of water. Switches OFF the motor within 40 seconds if it runs out of water and waits for 30 minutes before switching it ON again. Also, switches OFF the motor when the water level is high. Auto-off timer can be used for temporary filling up of water in the overhead tank (e.g. During scheduled powercut).

Bore motor


E-mail address: info@eviqds.com

Contact Mobile: +91 9629900110,+91-9443410073

Float Switch

Over head tank

Connection details of SWAP04-SOL (Sump and overhead tank water level controller) for Mono-block & Jet Pumps




E-mail address: info@evigds.com

Contact Mobile: +91 9629900110,+91-9443410073

EVI


Product & Sensor integration details of SWAP04-SOL (Sump and overhead tank water level controller) for Mono-block & Jet Pumps





E-mail address: info@eviqds.com

Connection details of SWAP04-C-SOL(Water level control for both sump and Overhead tank with Auto start capacitor option) for single phase Submersible motor



E-mail address: info@eviqds.com


Contact Mobile: +91 9629900110,+91-9443410073

EV

Connection details of SWAP04-C-SOL for 1phase Submersible starter 🔊 EVIQ

Step 3

Starter default appearance




While making any circuit connection first disconnect the power.




Step 1

First, remove the wire from any one terminal of the red push button, and then connect that same wire to the C-IN of the Auto-OFF Timer as shown in the image below.




Step 2 Take a new wire and connect one end to the red-Colored push button terminals and the other end to the C-out of the SWAP, as shown in the image below.








Now ,connect L1 and L2 across the starting capacitor, as shown in the image below. Then without removing the existing L&N wire of the Starter panel, loop the L&N terminal of the Auto OFF Timer to the Starter Panel.



Contact Mobile: +91 9629900110,+91-9443410073

Product & Sensor integration details of SWAP04-C-SOL(Water level) controller)



E-mail address: info@eviqds.com

Connection details of SWAP04-C-SOFL(Automatic Detection of Corporation water flow into the Sump with water level control for both Sump and Overhead tank) for single phase Submersible motor Single phase Starter ້າວ້າວ້າວ້າວ້າວ້າດ້າ **SWAP** Water Level Recommended cross section of wire controller MADE IN INDIA IS / IEC 60669-2 Connection 0.5 - 5 hp X-2HP-3kW-250V-50Hz **Terminals** (mm^2) Do not change polarity 1/1.5 L1, L2, L& N R Y B L2 L1 LOAD IN N **Motor wire** Only in Auto off timer mode: Select the required time on the SWAP Auto-off Timer. To select other time option while the current cycle is running, press the red button and select the time of Main supply vour choice. Water Pumps


E-mail address: info@evigds.com

Connection details of SWAP04-C-SOFL for single phase Submersible starter

Step 3



Starter default appearance




While making any wiring connection first disconnect the power.




Step 1

First, remove the wire from any one terminal of the red push button, and then connect that same wire to the C-IN of the Auto-OFF Timer as shown in the image below.




Step 2 Take a new wire and connect one end to the red-Colored push button terminals and the other end to the C-out of the SWAP, as shown in the image below.








Now ,connect L1 and L2 across the starting capacitor, as shown in the image below. Then without removing the existing L&N wire of the Starter panel, loop the L&N terminal of the Auto OFF Timer to the Starter Panel.



Contact Mobile: +91 9629900110,+91-9443410073


Product & Sensor integration details of SWAP04-C-SOFL






E-mail address: info@eviqds.com


Connection details of SWAP04-SMFL(Auto detection of Corporation water into the sump with sump level & flow control) for water pumps



E-mail address: info@eviqds.com




E-mail address: info@evigds.com



E-mail address: info@evigds.com

Product & Sensor integration details of SWAP04-OF(Over flow controller) for Mono-block & Jet Pumps






the remaining time in case of power interruption.

automatically switch OFF the motor after the selected time or if the tank water reaches its overflow limit .

Controller version. Please contact Us. Thanks.

E-mail address: info@evigds.com

Product & Connection details of SWAP04-OL-MFS (Overhead tank water level controller) for Mono-block & Jet Pumps




E-mail address: info@evigds.com

Contact Mobile: +91 9629900110,+91-9443410073

 $\mathbf{\Sigma} \mathbf{EVIO}$

Product & Sensor integration details of SWAP04-OL-MFS (Overhead tank water level controller) for Mono-block & Jet Pumps




E-mail address: info@eviqds.com

Contact Mobile: +91 9629900110,+91-9443410073

SEVI()


Product & Connection details of SWAP05E-BC Battery charger Timer for E-Vehicle battery chargers



E-mail address: info@eviqds.com

Product with 8 Module-Surface mount box installation








Fix the 8module box on wall & finish the wiring with SWAP module(Refer upcoming slides)

Step 2

Fix the cover plate, back onto the 8module box.




E-mail address: info@eviqds.com

To set the time in programmable auto-off timers







Once time setting is done simply press the timer Start button whenever you want to run the motor. For any other time just repeat the steps.

Step 1

Click the "+1" button to increment by 1 (or) Hold the "+1" button until the desired value.

Step 2

Click the "+5" button to increment by 5 (or) Hold the "+5" button until the desired value.


Step 3

Press and hold the "Set" button until the display turns off. If the time is still displayed, Hold the "Set" button again.


Step 4

Press "OFF" button and then "Start" button

E-mail address: info@evigds.com




E-mail address: info@eviqds.com



Contact Mobile: +91 9629900110,+91-9443410073


To set the cyclic time in programmable cycle timers (On & Off time)






E-mail address: info@eviqds.com

Product & connection details of Cyclic Timer-SWAP07ECY for Street, Compound & Signboard lightings



Contact Mobile: +91 9629900110,+91-9443410073

Product & connection details of Cyclic Timer-SWAP07ECYH for Street, Compound & Signboard lightings



Contact Mobile: +91 9629900110,+91-9443410073